SERVICE PARTS LIST

BUL. 54-46-0250

REVISED BUL 657-1 | DATE Feb. '68

WIRING INSTR.

DRILL STAND

MODEL NO. R-600 | Starting Serial No.

Both Model and Serial No. must be furnished to obtain correct parts.



Fig.	Part No.	Name of Part
1	69R-5	Base
2	6R-8	Post
3	69R-1	Cradle
4	69R-9	Coil Spring
5	69R-3	Handle
6	69R-2A	Bar Clamp
7	69R-4	Handle Link
8	36R4-1	Handle Link Pin
9	•69R2-100	Bar Clamp T Screw Ass'y.
10	69R-6	Bar Collar Stop
11	36R6-100	Bar Collar Stop T Screw Ass'y.
12	3/8"-16x1/2"	Base Set Screw (Allen Hd.)
13	5/16"-18 Thr'd.	Collar Stop Set Screw Wing Nut
14	5/16"-18x3"	Collar Adjusting Screw (Sq. Hd.)

Fig.	Part No.	Name of Part
15	36R7-1	Guide Bar Lock Bushing
16	1/4"-20x1"	Runner Adj. Screw (Fil.Hd.)
17	1/4"-20Thr'd.	Runner Lock Nut
18	36R7-2	Guide Bar Runner (each)
19	69R-7	Guide Bar
20	33/64"x7/8"x1/16"	Handle Swivel Screw Washer
21	36R3-1A	Handle Swivel Screw
22	69R-10	Band With Bushings
23	3/8"-16Thr'd.	Band Adj. Bolt Wing Nut
24	36R-12	Band Adj. Bolt
25	3/8"x7/8"x1/16"	Band Adj. Bolt Washer
26	3/16"x1-1/4"	Type "C" Driv-Loc Pin
27	5/16"x1-3/4"	Type "C" Driv-Loc Pin

MISCELLANEOUS PARTS (NOT SHOWN)

Size	Name of Part
	Name Plate
#4x1/4"	Name Plate Screws (2)
36R3-2	Swivel Screw Bushing